

1995 Volkswagen V.I.N. decoder

SERIES:

- B = Cabrio
 Golf 2dr III Sport
 C = Passat 4dr GLS
 D = Passat GLS Wagon
 E = Passat 4dr GLX
 EuroVan 3dr Panel
 F = Golf III 4dr GL
 Passat GLX Wagon
 H = GTI 2dr VR6
 Eurovan 3dr GL
 J = Golf III 4dr City
 EuroVan 4dr GL
 K = EuroVan 3dr GLS
 Golf III 4dr
 L = EuroVan GLS 4dr
 Golf III 4dr Celebrity Edition
 P = Jetta 4dr III
 R = Jetta III 4dr GL
 S = Jetta III 4dr GLS
 T = Jetta III 4dr GLX
 V = Jetta III 4dr City
 W = Jetta III 4dr Celebrity Edition

Canada Only:

- A = Cabrio
 Golf 2dr CL
 Passat 4dr GLS
 B = Golf 2dr GL
 Passat GLS Wagon
 C = Passat 4dr GLX
 D = Golf 2dr GTI
 Passat GLX Wagon
 E = Golf 4dr CL
 Corrado
 F = Golf 4dr GL
 P = Eurovan 3dr CV

NOTE:
 No "III" on
 the Canadian
 Jetta models

Country of origin	Manufacturer	Vehicle Type	Series	Engine	Restraint System	Model (position 7 & 8)	Check Digit	Model Year	Assembly Plant	Sequential serial number (position 12 - 17)						
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
3	V	W	R	A	8	1 H	1	S	M	0	1	1	2	3	4	
Country Code	Volkswagen	Type			See Chart		0-9 or X	1995			E = Emden H = Hannover M = Mexico K = Osnabrueck W = Wolfsburg					
		W = Car 1 = Truck 2 = MPV				MODEL: A = 4cyl 2.0L (G) Golf / Jetta / GTI (Except City) 115HP B = 4cyl 2.0L (G) Golf / Jetta / GTI / Cabrio 115HP C = 4cyl 2.0L (G) Golf / Jetta / Cabrio / Passat 115HP D = 6cyl 2.8L (G) Golf / Jetta / GTI (Except City) 172HP E = 6cyl 2.8L (G) Golf / Jetta / Passat 172HP E = 5cyl 2.5L (G) EuroVan 109HP F = 4cyl 1.9L (Diesel) Golf / Jetta / GTI 90HP 6cyl 2.8L (G) Corrado 172HP (Canada) G = 4cyl 1.8L (G) Golf / Jetta / GTI 90KW (Canada) G = 5cyl 2.4L (Diesel) EuroVan 77HP (Canada) H = 4cyl 1.9L (Diesel) Golf / Jetta / GTI 90HP					MODEL: 1E = Cabrio 1H = Golf / Jetta / GTI 3A = Passat 50 = Corrado* 70 = Eurovan *Canada Only					

S 1995



Volkswagen V.I.N. decoder

- ### '98 & Prior Restraints:
- 0 Active - Dr/Pass.
 - 2 Passive
W/manual lap.
 - 4 ELRA
W/manual lap.
 - 5 AirBag - Dr.
Active - Dr/Pass.
 - 6 AirBag - Dr/Pass.
Side AirBag Front
Dr/Pass.
 - Active - Dr/Pass.
 - 8 AirBag - Dr/Pass.
Active - Dr/Pass.
- NOTES:**
 All '98 Passat an
 New Beetle Vehicles
 are equipped with
 depowered AirBags.
- Dr = Driver Side
 Pass = Passenger Side

Country of origin	Manufacturer	Vehicle Type	Series	Engine	Restraint System	Model (position 7 & 8)	Check Digit	Model Year	Assembly Plant	Sequential serial number (position 12 - 17)						
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17

- ### '99 Restraints:
- Golf, GTI, Jetta, Cabrio, New Beetle & New Jetta:**
- 2 AirBag Dr/Pass (Depowered)
Side AirBag - Front Dr/Pass
 - 6 AirBag Dr/Pass (Standard)
Side AirBag - Front Dr/Pass
 - 8 AirBag - Dr/Pass. Active - Dr/Pass
- Passat, EuroVan, New Golf, New GTI:**
- 2 or 8 AirBag Dr/Pass. Active - Dr/Pass (Depowered)
 - 3 or 6 AirBag - Dr/Pass (Depowered)
Side AirBag - Front Dr/Pass
 - 4 AirBag Dr/Pass (Depowered)
Side AirBag - Front & Rear Dr/Pass

Check Digit:
 0-9 or "X"
 This is a calculated digit per
 NHTSA code to determine the
 validity of a complete Vehicle
 Identification Number.

Must follow steps in order!

- 1- Model Year (position #10)
Locate & use appropriate card.
- 2- Model Code (positions #7 & #8)
- 3- Vehicle Series (position #4)
- 4- Engine Code (position #5)

- ### Model Year
- A = 1980
 - B = 1981
 - C = 1982
 - D = 1983
 - E = 1984
 - F = 1985
 - G = 1986
 - H = 1987
 - J = 1988
 - K = 1989
 - L = 1990
 - M = 1991
 - N = 1992
 - P = 1993
 - R = 1994
 - S = 1995
 - T = 1996
 - V = 1997
 - W = 1998
 - X = 1999