




**DANGER**

**Danger of electrical shock, burns or death.** Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



**CAUTION**

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



NOTES:  
 (2) WIRE ROUTED THRU ROOF.  
 (1) ALL OUTLETS DOWN STREAM AND INCLUDING THIS OUTLET ARE GROUND FAULT CIRCUIT INTERRUPT PROTECTED.

- (265) CODES/STANDARDS-CSA/CMVSS
- (120) ELECTRICAL SYSTEM 30 AMP
- (1B1) CODES/STANDARDS USA

(120) (1B1) (265)

WINNEBAGO 02 222FD

DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL
DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL
DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL
DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL
DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL
DATE	UNSPECIFIED TOLERANCES ARE:	MATERIAL

WIRING DIAGRAM-BODY, 110V  
 SHEET 1 OF 1 I.E. NO. 137246  
 REF: 135985 A | PAGE 24