





DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



(CAN 110V WIRING)

- (4) NOT USED WITH 29K A/C. ROOF TWO 13,500.
- (3) WIRE ROUTED THRU ROOF.
- (2) WITH AIR CONDITIONER.
- (1) PROTECTED BY GFI RECP.

OF IN		DATE	UNDESIGNED TOLERANCES ARE	MATERIAL
CHP	DATE	ONE-PLACE (19, 21)		
PIE	DATE	TWO-PLACE (19, 21)		
D/E	DATE	ANGLE		
CONP	DATE	INDIC. W/ANGLE PROJECTION		
LAYOUT NO.		TITLE		98 222RC
REV #		SCALE	NOTE	WIRING DIAGRAM-BODY 110V
ALL DIMENSIONS ARE IN MILLIMETERS		SHEET	1 OF 1	126970