


8 7 6 5 4 3 2

Dwg No 119009



8

7

6


5



4

3

2

Dwg No 119009






INSTALL LABEL ON BACK SIDE OF CABINET ACCESS DOOR.

LABEL 95721-15-000

LOAD CENTER (US)
95 221RC
(SAME WITH OR
WITHOUT TWIN BEDS)


TITLE: WIRING INSTL-BODY
DRAWN BY: DATE: 4/6/13
REV: 1/10/13
119009

- (3) WITH TWIN BEDS.
- (2) WITHOUT TWIN BEDS.
- (1) ALL GROUND WIRES TO BE COVERED WITH TUBING 8041-02-000.



8 7 6 5 4 3 2

Dwg No 119009



⑤ SEAL BACK SIDE OF RECP FACE.
④ WIRE ROUTED IN SIDEWALL.

3. ALL GROUND WIRES TO BE COVERED WITH TUBING 8011-02-000.

2. ALL WIRES ARE TO BE CLAMPED WITH CLAMP 10497-05-000
WITHIN 200 OF OUTLET BOXES. USE SCREW G67-10-12B.

1. ALL WIRES TO BE CLAMPED WITH CLAMP 10495-01-000 OR
CLIP 20734-01-000 EVEN IF 60. USE SCREW G67-10-12B
UNLESS OTHERWISE SPECIFIED.

NOTES:

110V RIGHT (CAN)
95 22IRC
(WITHOUT TWIN BEDS)

TITLE: WIRING INSTL-BODY		
DO NOT SCALE DRAWING	REV	119009

8

7

6


5



4

3

2

Dwg No 119009





INSTALL LABEL ON BACK SIDE OF CABINET ACCESS DOOR.
LABEL 95721-16-000

LOAD CENTER (CAN)
95 221RC
(SAME WITH OR
WITHOUT TWIN BEDS)

TITLE: WIRING INSTL-BODY
DWG NO. 119009
DATE: 6/15/09

- (3) WITH TWIN BEDS.
(2) WITHOUT TWIN BEDS.
(1) ALL GROUND WIRES TO BE COVERED WITH TUBING 8041-02-000.

8

7

6


5

4

3

2

Dwg No 119009




12V LEFT (US/CAN)
95 22IRC
(W/O TWIN BEDS)

WIRING INSTL-BODY
Dwg No 119009

8 7 6 5 4 3 2

Dwg No 119009



(1) W/SHOWER SUMP SYSTEM.


(2) WITH TV. SEE TV INSTL-OVERHEAD FOR ADDITIONAL INFORMATION.

(3) SEE DRAWING INSTL-FRONT END FOR ADDITIONAL INFORMATION.

NOTES:

12V LEFT (US/CAN)
95 221RC
(W/TWIN BEDS)

WIRING INSTL-BODY		
DO NOT SCALE DRAWING	REV	119009
Sheet 10 of 15	1st Ed	



8

7

6


5

4

3

2

Dwg No 119009




12V RIGHT (US/CAN)
95 221RC
(W/TWIN BEDS)


(2) PILOT HOLES MUST BE DRILLED FOR SCREW CLEARANCE.

(1) W/TV ANTENNA.

NOTES:


WIRING INSTL-BODY
Dwg No 119009






- (6) WITH TV.
- (4) LOCATE TO RETAIN CABLE BUT NOT RESTRICT TRAVEL OF ANTENNA.
- (3) ADD RUBBER BUMPER TO ROOF UNDER EACH END OF ANTENNA IN DOWN POSITION WHICH MAY IN CONTACT WITH ROOF.
- (2) SEE DRAWING 76319-01-000 FOR ADDITIONAL INFORMATION.
- (1) USE WITH TV ANTENNA.

NOTES:



TITLE: WIRING INSTL-BODY		
DET-NF SECTION DRAWING	REV: E	Dwg No 119009
DATE 14 OCT 09	1st Ed	



EXTERIOR LIGHTING
95 22IRC
(SAME WITH OR
WITHOUT TWIN BEDS)

WIRING INSTL-BODY
Dwg No 119009